

Documentation:
CCTV Camera Lens
February 2015

The start setup made use of six identical Computar CCTV lenses.
The various cameras have different field of views.





Camera Settings

- Gamma:** Off
- MGC:** Manual (the little adjustment knob – use a small screwdriver – is turned until a subjective best trade-off between background noise and brightness of background stars is found).
- Iris level:** Turn the adjustment-knob in order to open the iris as much as possible. By turning the knob while looking into the camera one can see how the iris opens and closes.
- Shutter:** Shutter knob is set to 0 (zero) or 12 o'clock position.
- BLC:** All three BLC knobs switched to OFF (down position).





The following pictures show what to look for when closing the CCTV camera enclosure. The most important thing is to ensure the rubber sealing to be placed correctly.





